

# IDEC

## INSTRUCTION SHEET

# MICROSmart

### FC6A Series

#### Functional module

#### (Analog module / PID module)

This sheet provides brief operating instructions of the MicroSmart programmable controller. For details, see the FC6A Series MicroSmart User's Manual.

### Safety Precautions

Special expertise is required to use the MicroSmart.

- Read this instruction sheet and the user's manual to make sure of correct operation before starting installation, wiring, operation, maintenance, and inspection of the MicroSmart. Keep this instruction sheet where it can be accessed by the end user.
- All MicroSmart modules are manufactured under IDEC's rigorous quality control system, but users must add backup or failsafe provisions to control systems use the MicroSmart in applications where heavy damage or personal injury may be caused if the MicroSmart should fail.
- Install the MicroSmart according to the instructions described in this instruction sheet and the user's manual. Improper installation will result in falling, failure, or malfunction of the MicroSmart.
- Make sure that the operating conditions are as described in the user's manual. If you are uncertain about the specifications, contact IDEC before using the MicroSmart.
- In this instruction sheet, safety precautions are categorized in order of importance from Warning and Caution:

### WARNING

Warning notices are used to emphasize that improper operation may cause severe personal injury or death.

### CAUTION

Caution notices are used where inattention might cause personal injury or damage to equipment.

### WARNING

- Turn off the power to the MicroSmart before starting installation, removal, wiring, maintenance, or inspection on the MicroSmart.
- Failure to turn off the power may cause electrical shocks or fire hazard. Emergency stop and interlocking circuits must be configured outside the MicroSmart. If such a circuit is configured inside the MicroSmart, failure of the MicroSmart may cause disorder of the control system, damage, or accidents.
- Suitable for use in Class I, Division 2, Groups A,B,C and D Hazardous Locations, or Non-hazardous locations only.
- Warning - Explosion Hazard - Do not disconnect equipment while the circuit is live or unless the area is known to be free of ignitable concentrations.
- Avertissement: Risque d'explosion. Ne pas débrancher tant que le circuit est sous tension, à moins qu'il ne s'agisse d'un emplacement non dangereux
- Warning - Explosion Hazard - Substitution of any components may impair suitability for Class I, Division 2.
- Avertissement: Risque d'explosion. La substitution de composants peut rendre ce matériel inacceptable pour les emplacements de classe I, division 2
- This equipment is an open -type device meant to be installed in an enclosure suitable for the environment that is only accessible with the use of a tool of key.

### CAUTION

- The MicroSmart is designed for installation in equipment. Do not install the MicroSmart outside of equipment.
- Install the MicroSmart in environments as described in the user's manual. If the MicroSmart is used in places where it is subjected to high-temperature, high-humidity, condensation, corrosive gases, excessive vibrations, or excessive shocks it will result in electrical shocks, fire hazard, or malfunction.
- The environment rating for using the MicroSmart is "Pollution degree 2."
- Prevent metal fragments and pieces of wire from dropping inside the MicroSmart housing. Ingress of such fragments and chips may cause fire hazard, damage, or malfunction.
- Use wires of a proper size to meet voltage and current requirements. Tighten terminal screws to the proper tightening torque of 0.28 N-m or 0.49 N-m.
- Use an IEC60127-approved fuse on the power line and output circuit to meet voltage and current requirements. (Recommended fuse: Littelfuse 5x20mm slow-blow type 218000 series/Type T) This is required when exporting equipment containing MicroSmart to Europe.
- Use an EU-approved circuit breaker. This is required when exporting equipment containing MicroSmart to Europe.
- If relays or transistors in the MicroSmart output modules should fail, outputs may remain on or off. For output signals which may cause heavy accidents, provide a monitor circuit outside of the MicroSmart.
- Do not disassemble, repair, or modify MicroSmart modules.

### 1 TYPE


- Analog input module  
FC6A-J2C1, FC6A-J4A1, FC6A-J8A1, FC6A-J4CN1, FC6A-J8CU1
- Analog output module  
FC6A-K4A1
- Analog I/O module  
FC6A-L03CN1, FC6A-L06A1
- PID module  
FC6A-F2M1, FC6A-F2MR1

Applicable model  
FC6A Series MicroSmart CPU module

### 2 Specification


Operating Temperature: -10 to +55°C, Storage Temperature: -25 to +70°C (no freezing)  
Relative/Storage Humidity: 10 to 95%RH (no condensation),  
Altitude: 1013 to 795hPa (0 to 2,000 m) during operation 1013 to 701hPa (0 to 3,000 m) during transport,  
Vibration Resistance: 5 to 8.4 Hz half amplitude 3.5 mm, 8.4 to 150 Hz, acceleration 9.8 m/s<sup>2</sup> (1 G), X, Y, Z directions, 2 hours,  
Shock Resistance: 147 m/s<sup>2</sup> (15 G), 11 ms, X, Y, Z directions, 3 times  
\*See the user's manual for more details on the product specifications.

### 3 Parts Description






- Module label**  
Indicates the module Type No. and specifications.
- LED Indicator**  
Turns on when power is supplied to the analog I/O module./ For PID modules only, turns on in conjunction with the status.
- Terminal No.**  
Indicates terminal numbers.
- Cable Terminal**  
These terminals connect output devices, input devices or power.
- Expansion Connector**  
Connects to the CPU and other I/O modules.

### 4 Connecting Modules




### 5 Mounting Modules






For details about mounting and removing modules, see the user's manual.




### 6 Dimensions



### 7 Wiring



Wiring for 2-wire analog out sensor



### 8 Applicable Ferrule

The recommended ferrule is made by Phoenix Contact. To crimp the ferrules shown below, use a special crimping tool (CRIMPFOX 6 (1212034))

- F6A-J4A1, FC6A-J8A1, FC6A-J4CN1, FC6A-J8CU1, FC6A-L06A1, FC6A-F2M1, FC6A-F2MR1  
AI 0,25-8 (3203037), AI 0,25-10 (3241128), AI 0,34-8 (3203066),  
AI 0,34-10 (3241129), AI 0,5-8 (3200014), AI 0,5-8 GB (1208966),  
AI 0,5-10 (3201275), AI 0,5-10 GB (3203150) AI-TWIN 2 × 0,5-10 (3203309)
- FC6A-J2C1, FC6A-K4A1, FC6A-L03CN1  
AI 0,25-10 (3241128), AI 0,34-10 (3241129), AI 0,5-10 (3201275),  
AI 0,5-10 GB (3203150), AI-TWIN 2 × 0,5-10 (3203309), AI 0,75-10 (3201288),  
AI 1-10 (3200182), AI-TWIN 2 × 0,75-10 (3200975), AI 1,5-10 (3200195)

### 9 Recommended Screwdriver / Tightening torque

To wire the terminal block, use the recommended screwdriver made by Phoenix Contact and tighten terminal screws to the proper tightening torque.

- F6A-J4A1, FC6A-J8A1, FC6A-J4CN1, FC6A-J8CU1, FC6A-L06A1, FC6A-F2M1, FC6A-F2MR1  
Screwdriver : SZS 0,4×2,5 (1205037) / Tighten torque : 0.28 N-m
- FC6A-J2C1, FC6A-K4A1, FC6A-L03CN1  
Screwdriver : SZS 0,6×3,5 (1205053) / Tighten torque : 0.49 N-m

MicroSmart User's manual can be downloaded from <http://www.idec.com/download>