# PS6R



## Reduced size and high efficiency cuts operating costs.



• See website for details on approvals and standards.

#### **Energy-saving**

#### 93% Efficiency\*

Highly efficient saving energy and cost, improving productivity! \* When the input is 230V AC.



### Space-saving

The slimmest switching power supplies in their class (37mm-wide, 120W model)



### **Highly Reliable**

Wide operating temperature range enables stable continuous operation.

Operation without derating from 0 to  $60^{\circ}$ C. Wide operating temperature range: -10 to  $+70^{\circ}$ C.



APEM

Switches & Pilot Lights

Control Boxes Emergency Stop Switches

Enabling Switches

#### First in the industry **Convenient – Easily Expandable!**

Output voltages can be added or branched easily. Less wiring reduces overall cost.

#### DC-DC Converter Unit

In addition to a single output, an additional 10W output can be provided.

#### Required space comparison (480W model)



## **Reduces labor and improves safety**

#### **Reduced Wiring**



Captive spring-up screws will not be lost. Ring or fork terminals can be connected quickly and easily.

Fingersafe



Terminals cannot be touched (IP20 construction), preventing electric shocks.

#### Expansion Terminal Unit

Two terminals for wiring can be added, reduces wiring and installation space.







Circuit Protectors Power Supplies

LED Illumination

- Controllers
- Operator Interfaces
- Sensors
- AUTO-ID

PS5R-V

## **Easy Maintenance**

#### **LED Indicator**

LED indicators make maintenance easy.

Status	Normal	Overload or Input Voltage Low (Note)	Output Short-circuit	Output OFF
DC ON (green LED)	¥	- <b>X</b> -		
DC Low (amber LED)		-)	-)—-	•

Note: The LEDs go on when the input voltage drops.

- 1
- 1
- 1

Power Supplies

## **PS6R** Switching Power Supplies

## High-power and space-saving switching power supplies. 93% efficiency reduces running costs.

	P20K				Package Quantity: 1
APEM			ATTA LATTICE PARAMENTE	1	
Switches & Pilot Lights			cco, cco <u>cco</u>	lat.	
Control Boxes			THE REAL PROPERTY.		
Emergency Stop Switches	Shape				
Enabling Switches			see sees access		
Safety Products			120W 240W 480W		
Explosion Proof	Output Capacity (Note)	Part No.	Input Voltage	Output Voltage	Output Current
Terminal Blocks	120W	PS6R-F24			5A
	240W	PS6R-G24	100 to 240V AC (Voltage range: 85 to 264V AC / 110 to 350V DC)	24V	10A
Relays & Sockets	480W	PS6R-J24			20A

Circuit Note: Output voltage  $\times$  output current  $\leq$  output capacity Protectors

#### **Accessories**

LED Illumination				
	Item	Part No.	Package Quantity	Note
Controllers		PS9Z-6RM1		Output: +5V, 2A, 10W
Operator		PS9Z-6RM2		Output: +12V, 1A, 12W
Interfaces	DC DC Converter Unit (Note 1)	PS9Z-6RM3	1	Output: +5V, 1A/-5V, 1A, 10W
Sensors		PS9Z-6RM4	] '	Output: +15V, 0.4A/-15V, 0.4A, 12W
		PS9Z-6RM5		Output: +5V, 1A/+12V, 0.5A, 11W
AUTU-ID		PS9Z-6RM6	-	Output: +12V, 0.5A/–12V, 0.5A, 12W
	Expansion Terminal Unit (Note 2)	PS9Z-6RS1	1	Additional screw terminals for wiring:
			•	2 + terminals / 2 - terminals
	Panel Mounting Bracket	PS9Z-6R1F	1	
PS5R-V			•	
DOOD	Side-mount Panel Mounting Bracket (Note 3)	PS9Z-6R2F	1	Supplied with M3 $\times$ 6 countersunk mounting screws
PS6R	Terminal Protection Can	PS97-6CPN05	5	Used to cover the connection part of DC-DC
		1002 001100	Ū	converter unit/expansion terminal unit and PS6R.
	DIN Reil	BAA1000PN10	10	Material: Aluminum, Weight: 200g
		BAP1000PN10	10	Material: Steel plated, Weight: 320g
	End Clip	BNL6PN10	10	Applicable rail: BAA,BAP, Weight: approx.15g

Note 1: When using a DC-DC converter unit, reduce 1A from the output current of the PS6R.

Note 2: When using a expansion terminal unit, the total voltage/current of PS6R and the expansion terminal unit should not exceed the rated current/voltage of PS6R. Note 3: Use this mounting bracket when the switching power supply needs to comply with marine certification.

## **Specifications**

## PS6R

Pa	rt No.		PS6R-F24 (120W)	PS6R-G24 (240W)	PS6R-J24 (480W)		
	Input Voltage (Not	e 1) (Note 2)	100 to 240V AC (Voltage range: 85	to 264V AC/110 to 350V DC)			
	Frequency		50/60 Hz				
	Input Current	100V AC	1.4A	2.7A	5.5A	—	
	(Typical)	230V AC	0.7A	1.2A	2.3A		
	Inrush	100V AC	9A max. (Ta=25°C, at cold start)			APEM	
Ħ	Current	230V AC	20A max. (Ta=25°C, at cold start)			Cuuitahaa 9	
립	Leakage	120V AC	0.5mA max.			Pilot Lights	
	Current	230V AC	1mA max.			Control Boyes	
	Efficiency	100V AC	90%	90%	91%	Control Doxes	
	(Typical) (Note 3)	230V AC	90%	91%	93%	Emergency Stop Switches	
	Power Factor	100V AC	0.99	0.99	0.98	Enabling	
	(Typical)	230V AC	0.96	0.97	0.97	Switches	
	Rated Voltage/Cur	rent	24V/5A	24V/10A	24V/20A	Safety Products	
	Adjustable Voltage	e Range	±10%				
	Output Holding Tir	ne	20ms min. (at rated input and outp	ut)		Explosion Proof	
	Start Time (Note 4	.)	800ms max. (at rated input and ou	tput)		Terminal Blocks	
+ ا	Rise Time		200ms max. (at rated input and out	tput)			
đ		Total Fluctuation	±5% max.			Relays & Sockets	
0		Input Fluctuation	0.4% max.			Circuit	
	Regulation	Load Fluctuation	0.6% max.			Protectors	
	Temperature Cl	Temperature Change	0.05%/°C max. (-10 to +60°C)			Power Supplies	
		Rinnle (including noise)	1% p-p max. (0 to +60°C)				
	Tupple (including holse)		1.5% p-p max. (–10 to 0°C)				
		Overcurrent Protection	105 to 120% (auto reset) (output current when voltage drops by 5%)			Controllers	
Su	pplementary	Overvoltage Protection	Output off at 120% (Note 5)			Operator	
Fu	Operation Indicator		LED (green)	Interfaces			
		Voltage Low Indication	LED (amber)	LED (amber)			
		Between input and output terminals	3000V AC, 1 minute			AUTO-ID	
Die	electric Strength	Between input and ground terminals	2000V AC, 1 minute				
		Between output and ground terminals	500V AC, 1 minute	PS5R-V			
Ins	ulation Resistance		$100M\Omega$ min. 500V DC megger (bet (at room temperature and normal h	PS6R			
Op	erating Temperatur	e	-10 to +70°C (no freezing) (Note 2)	)			
0p	erating Humidity		20 to 90% RH (no condensation)				
Sto	orage Temperature		-25 to +75°C (no freezing)				
Sto	orage Humidity		20 to 90% RH (no condensation)				
Vibration Resistance			10 to 55 Hz, amplitude 0.375 mm (using one BNL6 each on the right and left of the PS6R) 2 hours each in 3 axes. 6 directions				
Shock Resistance			300 m/s <sup>2</sup> (150 m/s <sup>2</sup> when using a P (using one BNL6 each on the right				
	0	EMI	EN61204-3 (Class B)			_	
EN	IC	EMS	EN61204-3 (industrial)			_	
Safety Standards		1	UL508 (UL listed), ANSI/ISA 12.12.01, CSA C22.2 No. 107.1, No. 213 (c-UL listed), IEC/EN60950-1 EN62368-1 EN50178 EN62477-1				
Marine Standards (Note 6)		te 6)	ABS, DNV-GL (formerly GL)	·			
Ot	ner Standard		SEMI F47 (208V AC inpu only)			1	
De	gree of Protection		IP20 (IEC 60529)			1	
Dir	mensions (mm)		125 H × 37 W × 125 D	125 H × 60 W × 125 D	125 H × 85 W × 125 D	7	
We	eight (approx.)		630g	960g	1400g		
Terminal Screw			M3.5				

Note 1: Input voltage approved by safety standards is 100 to 240V AC. DC input is not approved by safety standards.

Note 2: For output derating curves and operating temperature approved by safety standards, see J-020.

Note 3: Under stable state.

Note 4: At light load, electric charge may remain inside the power supply after the power has turned off. Turn on the power after sufficient interval.

Note 5: Turn on the power 1 minute after the AC input is shut down.

Note 6: Use a side-mount panel mounting bracket (PS9Z-6R2F).

PS6R-J24 switching power supply needs a noise filter at the input (FN2070-10-06 made by SCHAFFNER)

Power Su

## Accessories (For use with PS6R)

uppli	Part No.					DC-DC Convert	ter Unit (Note 5)			Expansion Terminal Unit
S				PS9Z-6RM1	PS9Z-6RM2	PS9Z-6RM3	PS9Z-6RM4	PS9Z-6RM5	PS9Z-6RM6	PS9Z-6RS1
	Output Cap	acity		10W max.	12W max.	10W max.	12W max.	11W max.	12W max.	—
	Rated Voltage/Current		5V/2A	12V/1A	±5V/1A	±15V/0.4A	5V/1A, 12V/0.5A	±12V/0.5A	24V/10A max. (Note 1)	
APEM		Adju Ranç	stable Voltage je	Not available						
Switches &		Volta	ige Accuracy	±5% max.						—
Pilot Lights	Output	Start	Time (Note 6)	200 ms max. (at	rated output)					—
Control Boxes	υιμαι		Input Fluctuation	0.5% max.						
Emergency		u	Load Fluctuation	1.0% max.						
Stop Switches Enabling		egulati	Temperature Change	0.05%/max. (–10	) to +60°C)					—
Switches Safety Products	-		Ripple (including noise)	100mV max.	150mV max.	100mV max.	150mV max.	100mV max., 150mV max.	150mV max.	
European Dreaf	Supple- Overcurrent Protection		105% (auto reset	105% (auto reset)						
Explosion Proof	of mentary Functions Overvoltage Protection		voltage Protection	Output off at 120% (Note 2)				—		
Terminal Blocks	Operating T	empe	rature	-10 to +70°C (no freezing) (Note 3)						
Relays & Sockets	Operating H	lumidi	ty	20 to 90%RH (no condensation)						
Circuit	Storage Ter	npera	ture	-25 to +75°C (no freezing)						
Protectors	Storage Hu	midity		20 to 90% RH (no condensation)						
Power Supplies	Vibration Re	esistar	nce	10 to 55 Hz, amplitude 0.375 mm, 2 hours each in 3 axes, 6 directions (in combination with PS6R-F24/G24/J24)					J24)	
LED Illumination	Shock Resis	stance	)	300 m/s <sup>2</sup> (150 m/s <sup>2</sup> when using a PS9Z-6R1F panel mounting bracket), 3 times each in 6 directions (in combination with PS6R-F24/G24/J24)						
Controllers	EMC		EMI	EN61204-3 (Clas	s B) (in combinati	on with PS6R-F24/	G24/J24) (Note 4)			
EMC		EN61204-3 (industrial) (in combination with PS6R-F24/G24/J24) (Note 4)					—			
Interfaces	aces Safety Standards		UL508 (Listing), ANSI/ISA 12.12.01, CSA C22.2 No.107.1, No. 213 (c-UL listed), IEC/EN60950-1, EN62368-1, EN50178 EN62477-1 (in combination with PS6B-F24/G24/J24)				EN50178,			
Sensors	Narine Standards		ABS, DNV-GL (formerly GL) (in comination with PS6R-F24/G24/J24)							
AUTO-ID	Degree of Protection		ion	IP20 (IEC 60529)						
	Weight (app	orox.)		90g						30g
	Terminal So	rew		M3.5						

Note 1: Ensure that the current does not exceed the rated current of the PS6R. PS5R-V

Note 2: Repair is needed when output drops due to overvoltage protection. Contact IDEC.

Note 3: For output derating curves and operating temperature approved by safety standards, see J-020.

Note 4: When using PS6R-F24/G24 with PS9Z-6RM3/6RM4/6RM6, coil each output lines of PS9Z-\* around a ferrite core for one turn.

Note 5: DC-DC converter unit is non-isolated and cannot be used when insulation against PS6R output is required.

Note 6: Because each output has different start time on multi-output models, make sure of the correct operation before installation.

**Power Supplies** 

#### Operating Temperature vs. Output Current (Derating Curves) PS6R-F24/G24/J24 PS9Z-6R\*\*

(natural air cooling)

**Output Current vs. Input Voltage** (Derating Curves) PS6R-F24/G24/J24 (Ta=25°C)

**Overcurrent Protection** Characteristics PS6R-F24/G24/J24

**Overcurrent Protection** Characteristics PS9Z-6RM\*



around the switching power supply.

### **Operating Temperature approved by Safety Standards**

Part No.	UL508, CSA C22.2 No. 107. 1	EN60950-1, EN62368-1, EN50178, EN62477-1		
PS6R-F24	60°C	60°C		
PS6R-G24	60°C	60°C		
PS6R-J24	55°C	60°C		
PS9Z-6R**	60°C	60°C		

## **Parts Description**

PS6R-F24/G24/J24 Switching Power Supply



PS9Z-6RM1/M2/M5 **DC-DC Converter Unit** 



#### PS9Z-6RM3/M4/M6 **DC-DC Converter Unit**

-5V сом OUTPUT 1A OUTPUT 1A COM +5V F (PS6R-6RM3 shown) PS9Z-6RS1 **Expansion Terminal Unit** 





Γ

PS5R-V

Controllers

Operator Interfaces Sensors

AUTO-ID

#### PS6R-F24/G4/J24/PS9Z-6RS1

Marking	Name	Description	
L, N	Input Terminal	Voltage range: 85 to 264V AC/110 to 350V DC	
÷	Ground Terminal	Be sure to connect this terminal to a proper ground.	
+V, -V DC Output Terminals		+V: Positive output terminal -V: Negative output terminal	
VR.ADJ	Output Voltage Adjustment	Allows adjustment within $\pm 10\%$ . Turning clockwise increases the output voltage.	
DC ON	Operation Indicator (green)	Lights on when the output voltage is on.	
DC LOW Output Low Indicator (Amber)		Lights on when the output voltage drops approximately 80% of the rated value.	
DC OK	DC OK Output	Lights on when the output voltage is more than 80% of the rated value. NPN transistor output (50V DC max., 50 mA max.)	

#### PS9Z-6RM\*

Marking	Name	Description
+5V, +12V, +15V	DC Output Terminal	+5V side, +12V side, +15V side: +output side
–5V, –12V, –15V	DC Output Terminal	-5V side, -12V side, -15V side: -output side
СОМ	DC Output Terminal	0V side (wired internally to -V of PR6R-F24/G24/J24)



APEM

Switches &

Pilot Lights

Emergency

Enabling

Switches

Control Boxes

Stop Switches

Safety Products

Explosion Proof Terminal Blocks Relays & Sockets Circuit Protectors Power Supplies LED Illumination

## Dimensions

## PS6R-F24 (120W)







000



125

4









All dimensions in mm.

Tolerance: ±1mm

#### **PS9Z-6R1F** Panel Mounting Bracket



Panel cut-out

PS9Z-6R2F Side-mount Panel Mounting Bracket



#### When a PS9Z-6R1F is installed on PS6R



When a PS9Z-6R2F is installed on PS6R



**PS6R-F24** 

39.3

29.5

29.5

58

(Side view)

А

В

С

D

Е

PS6R-J24

23

87.3

29.5

31

106

(Back view)

PS6R-G24

10.5

62.3

29.5

31

81

PS5R-V PS6R

When using a PS9Z-6RM\* **DC-DC Converter Unit** 



#### When using a PS9Z-6RS1 **Expansion Terminal Unit**





All dimensions in mm.

Tolerance: ±1mm

	PS6R-F24	PS6R-G24	PS6R-J24
Α	58	81	106

APEM

Switches & Pilot Lights Control Boxes Emergency Stop Switches

Enabling Switches

Safety Products Explosion Proof

Terminal Blocks

Relays & Sockets

Power Supplies

LED Illumination Controllers

Circuit

Protectors

Operator Interfaces Sensors

AUTO-ID

#### Safety Precautions

Mount the PS6R in an enclosure. Do not use the PS6R alone as an Electric Facilities for General Use.

Use the PS6R for electric facilities for business use only.

- Do not use switching power supplies with electric equipment whose malfunction or inadvertent operation may damage the human body or life directly.
- Switches & Pilot Lights
   • Make sure that the input voltage and output current do not exceed the ratings.

   Control Boxes
   • Make sure that the input voltage and output current exceed the ratings, electric shock, fire, or malfunction may occur.
  - Do not touch the terminals of the switching power supply while input voltage is applied, otherwise electric shock may occur.
  - Provide the final product with protection against malfunction or damage that may be caused by malfunction of the switching power supply.
  - Operating temperatures should not exceed the ratings. Be sure to note the derating characteristics. If the operating temperature exceeds the ratings,

#### **Operating Instructions**

#### Notes for Installation

• The PS6R can be installed in the direction shown below only.



- Do not close the top and bottom openings of the PS6R to allow for heat radiation by convection.
- Maintain a minimum of 20 mm clearance around the PS6R, except for the top and bottom openings.
- When derating of the output does not work, provide forced air-cooling.
- Make sure to wire the ground terminal correctly.
- $\bullet$  Recommended tightening torque of the input and output terminals is 1.0 to 1.3 N·m (UL compliant: 0.8 N·m).
- The output voltage can be adjusted within  $\pm 10\%$  of the rated output voltage by using the V.ADJ control. Note that overvoltage protection may work when increasing the output voltage.
- When large shocks or heavy vibrations on the PS6R are expected, the use of DIN rail or PS9Z-6R2F side-mount panel mounting bracket is recommended.
- For wiring, use wires with heat resistance of 60°C or higher. Use copper wire
  of the following sizes. Wires of the following size must be used to comply with
  UL508, CSA C22.2 No. 107.1.

Model	Terminal	Wire Size/No. of Wire	Wire Type	Torque, in-ibs (N·m)
PS6R-F24 PS6R-G24	Input	18-14 AWG, 1-wire		
	Output	18-14 AWG, 1-wire, (18 AWG - 7A, 16 AWG - 10A, 14 AWG - 15A) 22-14 AWG, 1-wire (stripped wire length: 6 to 7mm)		7.0 (0.8)
	DC OK Output			—
	Input	18-14 AWG, 1-wire	Solid/Stranded	
PS6R-J24	Output	18-14 AWG, 1-wire, 2-wire When using 2-wire, use the wire of the same size for each terminal (18 AWG - 7A, 16 AWG - 10A, 14 AWG - 15A)		7.0 (0.8)
	output	12 AWG, 1-wire	Copper Solid/Stranded Use with UL- listed ring/folk crimp terminal.	
	DC OK Output	22-14 AWG, 1-wire (stripped wire length: 6 to 7mm)	Copper	—
PS9Z-6R* Output		18-14 AWG, 1-wire (18 AWG - 7A, 16 AWG -10A, 14 AWG - 15A)	Solid/Stranded	7.0 (0.8)

Cross section:

AWG22: 0.33mm<sup>2</sup>, AWG20: 0.52mm<sup>2</sup>, AWG18: 0.82mm<sup>2</sup> AWG16: 1.31mm<sup>2</sup>, AWG14: 2.0mm<sup>2</sup>, AWG12: 3.3mm<sup>2</sup> electric shock, fire, or malfunction may occur.

- Blown fuses indicate that the internal circuits are damaged. Contact IDEC for repair. Do not just replace the fuse and reoperate, otherwise electric shock, fire, or malfunction may occur.
- . Do not use the switching power supplies to charge rechargeable batteries.
- Do not overload or short-circuit the switching power supply for a long period of time, otherwise the internal elements may be damaged.
- Do not disassemble, repair, or modify the power supplies, otherwise the high voltage internal part may cause electric shock, fire, or malfunction.
- The fuse inside the PS6R switching power supply is for AC input. Use DC fuse for DC input.

#### **Applicable Crimp Terminal (reference)**



#### Mounting on DIN Rails

- · Fasten the DIN rail to a mounting plate using screws.
- When mounting the PS6R on a DIN rail, place the PS6R as shown. With the clamp inserted, press the PS6R towards the DIN rail.
- Use end clips BNL6 for fastening the PS6R on the DIN rail. When using with a PS9Z-6RM\* DC-DC converter unit, install the BNL6 on the left side of the PS6R first.

#### Removal

 Insert a flat screwdriver into the slot in the clamp, and pull out the clamp until it clicks. Turn the PS6R bottom out. When mounting the PS6R again, push in the latch first.

Removal

Mounting



APEM

Emergency Stop Switches

Enabling

Switches

Safety Products

Explosion Proof

Terminal Blocks

Relavs & Sockets

Circuit

AUTO-ID

PS5B-V

PS6R

#### **Operating Instructions**

## Installing the PS9Z-6R1F Panel Mounting Bracket

When excessive vibration or shock is anticipated, use the PS9Z-6R2F side-mount panel mounting bracket.

1. Push in the latch on the PS6R and insert the tab on the panel mounting bracket into the slot on the PS6R.



2. Install the bracket as shown below.



3. Ensure that the panel mounting bracket is locked by the latch.

ſ	ſ	~		
			۵	Ŋ
			$\sim$	

#### Installing the PS9Z-6R2F Panel Mounting Bracket

Install the bracket on the PS6R using the  $M3 \times 6$  countersunk mounting screws supplied with the bracket.

Recommended tightening torque: 0.5 to 0.6 N·m



#### Adjustment of Output Voltage

The output voltage can be adjusted within  $\pm 10\%$  of the rated output voltage by using the VR.ADJ control on the front. Turning the VR.ADJ clockwise increases the output voltage. When using a higher output voltage, reduce the output current to make sure that the output capacity is within the rating. Note that overvoltage protection may work when increasing the output voltage.

#### **Overcurrent Protection**

The output voltage drops automatically when an overcurrent flows due to an overload or short circuit. Normal voltage is automatically restored when the load returns to normal conditions.

#### **Overvoltage Protection (OVP)** PS6R-F24/G24/J24 Power Supplies

When the output voltage has dropped due to an overvoltage, turn the input off, and after one minute, turn the input on again.

#### PS9Z-6RM\* DC-DC Converter Unit

Internal parts are damaged when the output voltage had dropped due to overvoltage. Contact IDEC.

#### Insulation/Dielectric Test

When performing an insulation/dielectric test, short-circuit the input (between L and N) and output (between +V and -V). Do not apply or interrupt the voltage quickly, otherwise surge voltages may be generated and the PS6R may be damaged.

#### Notes for Operation

- 1. Output interruption may indicate blown fuses. Contact IDEC.
- 2. The PS6R contains an internal fuse for AC input. When using DC input, install an external fuse or DC input. To avoid blown fuses, select a fuse in consideration of the rated current of the internal fuse.

#### Rated Current of Internal Fuses

Part No.	Internal Fuse Rated Current	
PS6R-F24	4A	
PS6R-G24	6.3A	
PS6R-J24	10A	

- · Avoid overloads and short-circuits for a long period of time, otherwise internal elements may be damaged.
- DC input operation is not subjected to safety standards.

#### Rust and Scratches on Housing, Frame, and Metal

Parts Bonded steel plates and hot-dip galvanized steel plates are used for the PS6R switching power supplies, and may develop scratches on the surface on the edge depending on the storage condition.

#### Noise

Small acoustic noise inside the power supply may be heard depending on the input voltage and load, but the performance of the PS6R is not affected. Power Supplies

#### APEM Switches &

Pilot Lights Control Boxes

Emergency Stop Switches Enabling

Switches

Safety Products

Explosion Proof

Terminal Blocks

Relavs & Sockets

Circuit Protectors

LED Illumination

Controllers Operator Interfaces

Sensors AUTO-ID

PS5R-V

#### **Operating Instructions**

#### Series Operation

The following series operation is allowed. Connect Schottky barrier diodes D as shown below. DC-DC converter unit cannot be connected in series.



Controllers

Operator Interfaces

Sensors

AUTO-ID

PS5B-V

PS6R



Select a Schottky diode in consideration of the rated current. The diode's reverse voltage must be higher than the PS6R's output voltage.

#### Parallel Operation

Parallel operation is possible to increase the output capacity. DC-DC converter unit cannot be connected in parallel.



## Operating Instructions

#### Warranty

IDEC warrants the PS6R switching power supply for a period of three years from the date of shipment.

#### Scope

IDEC agrees to free repair or replacement of the PS6R switching power supply if the product has been aparted under the following conditions.

supply if the product has been operated under the following conditions. The maximum value of output capacity is within the range shown in "Operating Temperature vs.

#### Output Current on J-020.

- Average operating temperature (ambient temperature of switching power supply) is 40°C at maximum.
- 2. The load is 80% at maximum.
- 3. Input voltage is the rated input voltage.
- 4. Standard mounting style

#### When increasing the capacity, observe the followings.

- 1. Maintain the operating temperature below 40°C.
- 2. Output cannot be connected directly in parallel operation. Connect a diode to the output of each PS6R.
- Output terminal voltage of both power supplies must be the same. Also, maintain the voltage difference between the power supplies below 30mV.
- 4. Use load lines of the same diameter and length.
- 5. Set the output voltage higher for the amount of diode forward voltage drop.
- 6. Turn on the inputs at the same time.
- 7. Select a diode in consideration of:
  - Diode's reverse voltage must be higher than the PS6R's output voltage. Diode's current must be three times as the PS6R's output current. Provide a heat sink for heat dissipation.

#### **Backup Operation**

Backup operation is a connection method of two switching power supplies in parallel for emergency. Normally one switching power supply has a sufficient output. If one switching power supply fails, another one operates to continue the output. Make sure that the sum of power consumption by load and diode is not greater than the rated wattage (rated voltage  $\times$  rated current) of one switching power supply.

IDEC shall not be liable for other damages including consequential, contingent or incidental damages. Warranty does not apply if the PS6R switching power supply was subject to:

1. Inappropriate handling, or operation beyond the specifications.

- 2. Modification or repair by other than IDEC.
- 3. Failure caused by other than the PS6R switching power supply.
- 4. Failure caused by natural disasters.

J-025

## **Ordering Terms and Conditions**

#### Thank you for using IDEC Products.

By purchasing products listed in our catalogs, datasheets, and the like (hereinafter referred to as "Catalogs") you agree to be bound by these terms and conditions. Please read and agree to the terms and conditions before placing your order.

#### 1. Notes on contents of Catalogs

(1) Rated values, performance values, and specification values of IDEC products listed in this Catalog are values acquired under respective conditions in independent testing, and do not guarantee values gained in combined conditions.

Also, durability varies depending on the usage environment and usage conditions.

- (2) Reference data and reference values listed in Catalogs are for reference purposes only, and do not guarantee that the product will always operate appropriately in that range.
- (3) The specifications / appearance and accessories of IDEC products listed in Catalogs are subject to change or termination of sales without notice, for improvement or other reasons.
- (4) The content of Catalogs is subject to change without notice.

#### 2. Note on applications

- (1) If using IDEC products in combination with other products, confirm the applicable laws / regulations and standards. Also, confirm that IDEC products are compatible with your systems, machines, devices, and the like by using under the actual conditions. IDEC shall bear no liability whatsoever regarding the compatibility with IDEC products.
- (2) The usage examples and application examples listed in Catalogs are for reference purposes only. Therefore, when introducing a product, confirm the performance and safety of the instruments, devices, and the like before use. Furthermore, regarding these examples, IDEC does not grant license to use IDEC products to you, and IDEC offers no warranties regarding the ownership of intellectual property rights or non-infringement upon the intellectual property rights of third parties.
- (3) When using IDEC products, be cautious when implementing the following. Use of IDEC products with sufficient allowance for rating and performance
  - ii. Safety design, including redundant design and malfunction prevention design that prevents other danger and damage even in the event that an **IDEC** product fails
  - Wiring and installation that ensures the IDEC product used in your iii. system, machine, device, or the like can perform and function according to its specifications
- (4) Continuing to use an IDEC product even after the performance has deteriorated can result in abnormal heat, smoke, fires, and the like due to insulation deterioration or the like. Perform periodic maintenance for IDEC products and the systems, machines, devices, and the like in which they are used.
- (5) IDEC products are developed and manufactured as general-purpose products for general industrial products. They are not intended for use in the following applications, and in the event that you use an IDEC product for these applications, unless otherwise agreed upon between you and IDEC, IDEC shall provide no guarantees whatsoever regarding IDEC products.
  - Use in applications that require a high degree of safety, including nuclear power control equipment, transportation equipment (railroads / airplanes / ships / vehicles / vehicle instruments, etc.), equipment for use in outer space, elevating equipment, medical instruments, safety devices, or any other equipment, instruments, or the like that could endanger life or human health
  - ii. Use in applications that require a high degree of reliability, such as provision systems for gas / waterworks / electricity, etc., systems that operate continuously for 24 hours, and settlement systems
  - Use in applications where the product may be handled or used deviating from the specifications or conditions / environment listed in the Catalogs. such as equipment used outdoors or applications in environments subject to chemical pollution or electromagnetic interference If you would like to use IDEC products in the above applications, be sure to consult with an IDEC sales representative.

## DEC CORPORATION

#### Head Office

6-64, Nishi-Miyahara-2-Chome, Yodogawa-ku, Osaka 532-0004, Japan

USA	IDEC Corporation	Tel: +1-408-747-0550	opencontact@idec.com	Taiwan	IDEC Taiwan Corporation
Germany	APEM GmbH	Tel: +49-40-25 30 54-0	service@eu.idec.com	Hong Kong	IDEC Izumi (H.K.) Co., Ltd.
Singapore	IDEC Izumi Asia Pte. Ltd.	Tel: +65-6746-1155	info@sg.idec.com	China/Shanghai	IDEC (Shanghai) Corporation
Thailand	IDEC Asia (Thailand) Co., Ltd	Tel: +66-2-392-9765	sales@th.idec.com	China/Shenzhen	IDEC (Shenzhen) Corporation
Australia	IDEC Australia Pty. Ltd.	Tel: +61-3-8523-5900	sales@au.idec.com	China/Beijing	IDEC (Beijing) Corporation
India	IDEC Controls India Private Limited	Tel: +91-80679-35328	info_india@idec.com	Japan	IDEC Corporation

Specifications and other descriptions in this brochure are subject to change without notice.

#### 3. Inspections

We ask that you implement inspections for IDEC products you purchase without delay, as well as thoroughly keep in mind management/maintenance regarding handling of the product before and during the inspection.

#### 4. Warranty

(1) Warranty period

The warranty period for IDEC products shall be one (1) year after purchase or delivery to the specified location. However, this shall not apply in cases where there is a different specification in the Catalogs or there is another agreement in place between you and IDEC.

(2) Warranty scope

Should a failure occur in an IDEC product during the above warranty period for reasons attributable to IDEC, then IDEC shall replace or repair that product, free of charge, at the purchase location / delivery location of the product, or an IDEC service base. However, failures caused by the following reasons shall be deemed outside the scope of this warranty.

- The product was handled or used deviating from the conditions / i environment listed in the Catalogs
- ii The failure was caused by reasons other than an IDEC product
- iii. Modification or repair was performed by a party other than IDEC
- The failure was caused by a software program of a party other than iv IDEC
- v. The product was used outside of its original purpose
- Replacement of maintenance parts, installation of accessories, or the like vi. was not performed properly in accordance with the user's manual and Cataloos

vii. The failure could not have been predicted with the scientific and technical standards at the time when the product was shipped from IDEC

viii. The failure was due to other causes not attributable to IDEC (including cases of force majeure such as natural disasters and other disasters)

Furthermore, the warranty described here refers to a warranty on the IDEC product as a unit, and damages induced by the failure of an IDEC product are excluded from this warranty.

#### 5. Limitation of liability

The warranty listed in this Agreement is the full and complete warranty for IDEC products, and IDEC shall bear no liability whatsoever regarding special damages, indirect damages, incidental damages, or passive damages that occurred due to an IDEC product.

#### 6. Service scope

The prices of IDEC products do not include the cost of services, such as dispatching technicians. Therefore, separate fees are required in the following cases.

- (1) Instructions for installation / adjustment and accompaniment at test operation (including creating application software and testing operation, etc.)
- (2) Maintenance inspections, adjustments, and repairs
- (3) Technical instructions and technical training
- (4) Product tests or inspections specified by you

The above content assumes transactions and usage within your region. Please consult with an IDEC sales representative regarding transactions and usage outside of your region. Also, IDEC provides no guarantees whatsoever regarding IDEC products sold outside your region.

## 🗆 www.idec.com



